



NFκB Luciferase Reporter Stable Cell Line (For Research Use Only)

HeLa – catalog number SL-0001
A549 – catalog number SL-0014

NIH/3T3 – catalog number SL-0006
HepG2 – catalog number SL-0017

HEK293 – catalog number SL-0012

Introduction

NFκB plays an important role in controlling many biological processes including immune and inflammatory responses, developmental processes, cellular growth, and apoptosis. In response to the various stimuli, such as stress, cytokines, free radicals, ultraviolet irradiation, and bacterial or viral antigens, NFκB is activated and translocates from cytoplasm to nucleus, where NFκB binds to its response element on the promoter region and regulates a wide spectrum of gene expression. Dysfunction of NFκB activity is associated with cancer, inflammatory and autoimmune disease, and viral infection. Monitoring the NFκB activity is essential to unveil the mechanism of these diseases and conduct drug discovery.

Product description

Signosis has developed NFκB luciferase reporter stable cell line by co-transfecting NFκB luciferase reporter vector and hygromycin expression vector. The hygromycin resistant clones were subsequently screened for TNFα-induced luciferase activity. The cell line can be used as a reporter system for monitoring the activation of NFκB triggered by stimuli treatment, such as TNFα, IL-1α and IL-1β, gene overexpression and gene knockdown.

Materials provided

One vial of 2×10^6 cells, at passage 4, in Freezing Media. **IMPORTANT:** store the frozen cells in liquid nitrogen until you are ready to thaw and propagate them.

Handling cells upon arrival

It is strongly recommended that you propagate the cells by following instructions as soon as possible upon arrival.

IMPORTANT: It is imperative that an adequate number of frozen stocks be made from early passages as cells will undergo genotypic changes. Genetic instability in transfected cells will result in a decreased responsiveness over time in normal cell culture conditions.

Required Cell Culture Media

- **Complete Growth Media**

In 450mL of DMEM, add 50mL FBS (10% final) and 5mL Penicillin/Streptomycin (1% final).

*In 450mL of EMEM, add 50mL FBS (10% final) and 5mL Penicillin/Streptomycin (1% final).

- **2x Freezing Media**

Add 10% DMSO (final) to Complete Growth Media and sterile-filter. Make fresh each time.

Materials required but not provided


(May be substituted with a comparable third-party product)

- Dulbecco's Modified Eagle's Medium (DMEM) -- *Hyclone P/N SH30243.01*
- Eagle's Minimum Essential Medium* (EMEM) -- *ATCC P/N 30-2003*
- Fetal Bovine Serum (FBS) -- *Fisherbrand P/N 03-600-511*
- Penicillin/Streptomycin -- *Hyclone P/N SV30010*
- Trypsin -- *Hyclone P/N SH30236.02*
- Phosphate-buffered saline (PBS) -- *Cellgro P/N 21-040-CV*
- DMSO -- *Sigma P/N D8418*
- 96-well white plate -- *Greiner Bio-One P/N 655098*
- Luciferase assay -- *Signosis P/N LUC100*
- Passive lysis buffer -- *Promega P/N E-1941*
- Hygromycin B -- *Toku-E P/N H010 (OPTIONAL)*

*only for HepG2 (SL-0017)

Available NFκB reporter cell lines

HeLa (human cervical carcinoma) – SL-0001
NIH/3T3 (mouse embryonic fibroblast) – SL-0006
HEK293 (human embryonic fibroblast) – SL-0012
A549 (human lung carcinoma) – SL-0014
HepG2 (human liver carcinoma) – SL-0017



Initial Culture Procedure

1. Quickly thaw cells in a 37°C water bath with careful agitation. Remove from bath as soon as the vial is thawed.
2. Transfer cells to a T25cm² flask (or 60mm² dish) containing 5-10ml of **Complete Growth Media**.
3. Gently rock the flask to ensure the cells are mixed well in the media. **DO NOT PIPET**.
4. Place the flask with cells in a humidified incubator at 37°C with 5% CO₂.
5. After cells adhere (wait at least 4 hours to overnight), **replace media** with fresh Complete Growth Medium.

Subculture Procedure

1. Subculture/passage cells when density reaches 90-100% confluency.
2. Carefully remove the culture media from cells by aspiration.
3. Rinse cells with PBS, being careful not to dislodge attached cells. Then remove PBS by aspiration.
4. Add 1-2 mL trypsin/Tris-EDTA solution. **DO NOT** add directly to cells.

5. Incubate with trypsin for 2-5 minutes (or until detached). Confirm detachment by observation under the microscope.
6. Add 5-10ml of pre-warmed Complete Growth Media and gently pipet up and down to break the clumps.
7. Passage cells in 1:3 to 1:5 ratio when they reach 90% confluency.

NOTE: Stable cell line may exhibit slower proliferation rate compared to parental cells. Do not seed cells at suboptimal density as this may hinder cell growth and division.

Preparing frozen stocks

This procedure is designed for 100mm² dish or T75cm² flask. Scale volumes accordingly to other vessels.

1. When cells reach 90-100% confluency, freeze down cells.
2. Detach cells according to “Subculture Procedure.”
3. Transfer cells to a 15ml conical centrifuge tube and centrifuge at 250 x g (or 2,000 RPM) for 5 minutes to collect the cells into a pellet.
4. Carefully aspirate the media and resuspend cells in 0.5mL complete growth media.
5. Add 0.5mL of 2X freezing media and gently resuspend by pipetting up and down.
6. Transfer 1mL of cells into a cryogenic vial.
7. Place cryogenic vial in a freezing container (*Nalgene # 5100-0001*) and store at -80°C freezer overnight.
8. Transfer cells to liquid nitrogen for long term storage.

Assay procedure

The following procedure should be followed as a guideline. You will need to optimize the assay conditions based upon your experimental set up.

1. The day before performing the assay, trypsinize the cells and seed each well of a 96-well **white-wall** plate with 1×10^4 cells in 100µl.
2. Incubate the plate in a humidified incubator at 37°C with 5% CO₂ overnight.
3. Add inducing reagent directly to each well and incubate for an appropriate time to produce maximal induction.
4. Remove the media by aspiration and add 100µl of PBS to each well.
5. Remove PBS by aspiration and add 20µl of passive lysis buffer to each well.
6. Incubate cells in lysis buffer for 15 minutes at room temperature.
7. Add 100µl of luciferase substrate to each well and gently pipette up and down.
8. Immediately read the plate in a luminometer.